

# homesmart®

## *2 in 1 Glass Bowl Air Fryer*

### Instruction Manual



**Model No: AF-10D**

**Please read this manual carefully and keep it for reference.**

# Safety Instructions

This appliance may be used by children from the age of 8 and up, and also by persons with physical, sensory, or mental limitations, as well as those with a lack of experience and knowledge, but only on the condition that these persons have received the necessary instructions on how to use this appliance safely and understand the associated risks.

This appliance is not to be used by persons (including children) with reduced physical, sensory, or mental capabilities, or those lacking experience and knowledge unless they have been given supervision or instruction.

Children should not be allowed to play with the appliance. Maintenance and cleaning of the appliance may not be done by children unless they are over 16 years old and under supervision.

Keep the appliance out of the reach of children younger than 16 years old.

This appliance is suitable for household use and similar environments, such as:

- Kitchens in shops, offices, or other professional environments
- Farms
- Hotel or motel rooms with a residential character
- Guest rooms or similar accommodations

**Attention:** This appliance cannot be used with an external timer or separate remote control.

## General Safety Tips

- Read all instructions before use.
- Before use, check that the voltage indicated on the rating label corresponds to the local network before connecting the appliance to the mains power supply.
- Do not allow the cord to hang on a hot surface or over the edge of a table or countertop.
- If the supply cord is damaged, a qualified engineer must replace it to avoid hazards, or the unit should be sent to the authorized after-sales service centre for repair.
- Close supervision is necessary when the appliance is used near or by children.
- The use of accessories not recommended or sold by the manufacturer can cause fire, electric shock, or injury.
- Unplug the appliance when not in use, before assembling or disassembling parts, and before cleaning. Put all buttons and knobs into the 'Off' position and unplug the appliance by grasping the plug. Never unplug by pulling the cord.
- Do not leave a working appliance unattended.
- Never place this appliance near a gas stove or electric stove or in a location where it may come into contact with a heated appliance.
- The appliance should only be used with the stand provided.
- Do not use the appliance outdoors.

- Only use the appliance for its intended purpose.
- Always use the appliance on a steady, dry, and level surface.
- Only use the appliance for domestic use. The manufacturer cannot be held responsible for accidents that result from improper use of the appliance or from not following the instructions in this manual.
- All repairs should be carried out by the manufacturer or authorized after-sales service.
- Never immerse the appliance, cord, or plug in water or any other liquid.
- Ensure that children do not touch the cord or appliance.
- Keep the cord away from sharp edges and hot parts or other heat sources.
- Before use, remove all packaging materials and promotional stickers.
- Never leave the appliance unattended while it is operating.
- Do not use or store this appliance outdoors.
- Do not use this appliance for anything other than its intended use.
- Check that the voltage and frequency of the power supply match the indications on the appliance's rating label.
- The plug must be plugged into an appropriate outlet that is installed and grounded in accordance with all local standards and requirements.
- Only use the utensils provided with the appliance.
- Do not operate this appliance if the cord or plug is damaged or if the appliance malfunctions or has been damaged in any way. Return the appliance to the Service Department or an authorized service agent for examination, repair, or electrical or mechanical adjustment. Do not attempt to repair the appliance yourself.
- To protect against electric shock or burns, do not immerse the unit, cord, or plug in water or any other liquid.
- Do not operate the appliance with wet hands.
- Unwrap the cord completely to prevent overheating.
- Do not let the power cord hang over the edge of a counter or touch hot surfaces.
- Do not allow the power supply cord to run underneath or around the unit.
- Never pull the cord or appliance to remove the plug from the socket.
- Do not use the appliance if there is any water in it or if parts are still wet after cleaning.
- Do not use the appliance without ingredients.
- Handle sharp accessories, like blades, with great care. Only touch accessories when they have stopped moving inside the appliance.
- Failure to maintain this appliance in a clean condition may adversely affect the appliance's lifespan and possibly create a hazardous situation.
- Any injury or damage caused by failure to comply with these instructions is at your own risk. Neither the manufacturer, importer, nor the supplier may be held liable.

## **SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE**

### **Before First Use**

1. Carefully unpack the unit and remove all packing materials. Place the unit on a flat, heat-resistant, non-flammable surface. Do not immerse the appliance in water or any other liquid.
2. Wipe the unit clean with a soft, damp cloth and dry thoroughly.

*Note:* When using for the first time, a slight odour may be emitted. This is not harmful and will disappear after a few minutes. This occurs because protective oil was applied to parts to prevent friction during transport.

### **Using the Air Fryer**

- **STEP 1:** Ensure that the Air Fryer is switched off and unplugged from the mains power supply.
- **STEP 2:** Position the Air Fryer on a flat, stable, heat-resistant surface at a comfortable height for the user.
- **STEP 3:** Pull the glass container out of the air fryer using the handle, place the mesh rack into the glass container, and then put the food onto the mesh rack.
- **STEP 4:** Push the glass container back into the air fryer.
- **STEP 5:** Plug the cable into the power cord socket. Then, select your desired cooking time and temperature.
- **STEP 6:** Once cooking is complete, switch off the Air Fryer at the mains power supply.
- **STEP 7:** Ensure the unit is not turned on without any food inside.

## Product Overview




1. Digital Control Dial	2. Head
3. Detachable Glass Jug	4. Jug Handle
5. Air Outlet	6. Release Button
7. Mesh Rack	8. Grill pan

### **Features:**

Voltage	220~240V
Rated power	1200-1400W
Frequency	50/60Hz
Temperature Range	40~200 °C
Time	0-60 minutes
Capacity	4.5L
Net weight	6.0 kg




**Warning: Below is the correct method of using an Air fryer :**



**Warning:** Before using Please take out the paper holder inside the unit

### **Basic Accessories:**



Mesh Rack




Grill Pan

Item	Description
Mesh Rack	For holding food such as Fries, chicken wings., etc
Grill Pan	For steak, salmon fish


## How to Use the Accessories:

### 1. Using the Mesh Rack for Fries and Chicken Wings:


- When using as an air fryer, pull the glass container out, place the mesh rack with food on it, and then push the glass container back into the air fryer.  
(Please see photos below for reference)



(1)




(2)




(3)

### Using the Grill Pan for Steak:

- For grilling, pull the glass container out, press the button on the right side panel, turn the head upside down, and place the grill pan on it.  
(Please see photos below for reference)




(1)



(2)






(3)



(4)

## Control Panel:



<u>Number</u>	<u>Function</u>
1. 	Power Button: Used to turn the appliance on/off and pause cooking.
2. 	Mode Selection: Used to switch between preset cooking modes.
3. <u>DIY</u>	DIY Button: Used to set your own cooking recipe.
4. +	Button: Adjusts the timer and temperature.
5. -	Button: Adjusts the timer and temperature.
6. 	Set Button: Sets your desired cooking temperature and time

Note: For more detailed information, see the later sections.

## COOKING:

1. Select the desired cooking method, whether using the included mesh rack or grill pan.
2. Add the food to the air fryer. If using the mesh rack, place the food on it before inserting it into the air fryer.
3. Insert the power cord firmly into the wall AC outlet.
4. If the glass container is pulled out during cooking, the air fryer will pause, and "E5" will appear on the display. The timer will continue, but the unit will not heat. Once the glass container is reinserted, cooking will resume.



5. When the timer reaches zero, the air fryer will beep to indicate cooking has finished, and the unit will stop operating.

*Note: The fan will continue to work for around 1 minute to cool the motor, even after cooking has stopped.*

## OPERATION:



BUTTON:

Press the  button on the control panel to turn the appliance on.


There are two ways to use the air fryer, one is using the pre-set menu cooking times and temperatures, the other is to manually set your desired time and temperature.


## PRESET MENU COOKING:



Press the  button on the control panel.





Press the  button repeatedly to choose between the different menu cooking options.

When your chosen option has been selected and is shown on the screen, press the  button on the control panel to start the cooking process.


Menu	Temperature	Time
French Fries	160 °C	25 mins
Cake	180 °C	30 mins
Pizza	180 °C	15 mins
Chicken	200 °C	25 mins
Chicken Wing	200 °C	20 mins
Fish	180 °C	10 mins
Shrimp	180 °C	15 mins
Steak	200 °C	20 mins

## SETTING THE TIMER AND THE TEMPERATURE:


Press the  button on the control panel, then press the  button.

The temperature will then be flashing on the screen. While it is flashing, you can adjust the temperature. Press the + or – buttons on the control panel to adjust the temperature.

When your desired temperature is shown on the screen, you can then adjust the timer.

Press the  button on the control panel again and the time will then be flashing on the screen.

Press the + or – buttons on the control panel to adjust the time.

When the time has been set, press the  button on the control panel to start the cooking process.


The maximum temperature which can be set is 200 Degrees Celsius.

The minimum temperature which can be set is 40 Degrees Celsius.

The maximum time which can be set is 1 hour.

The minimum time which can be set is 1 minute


## DIY COOKING:

Press the  button on the control panel to turn the appliance on.


Press the DIY button on the control panel.

The temperature will then be flashing on the screen. While it is flashing, you can adjust the temperature. Press the + or – buttons on the control panel to adjust the temperature.

When your desired temperature is shown on the screen , you can then adjust the timer.

Press the  button on the control panel again and the time will then be flashing on the screen.

Press the + or – buttons on the control panel to adjust the time.

When the time has been set, press the  button on the control panel to start the cooking process.

The maximum temperature which can be set is 200 Degrees Celsius.

The minimum temperature which can be set is 40 Degrees Celsius.


The maximum time which can be set is 15 hour.


The minimum time which can be set is 1 minute.

Default time: 30 minutes

Default temperature: 40 Degrees Celsius.


## Grill or Hot Pot

Press the  button on the control panel to turn the appliance on. The display will show “00:00”.


Press the DIY button on the control panel, then press the  button.

The temperature will then be flashing on the screen. While it is flashing, you can adjust the temperature. Press the + or – buttons on the control panel to adjust the temperature.

When your desired temperature is shown on the screen, you can then adjust the timer.

Press the  button on the control panel again and the time will then be flashing on the screen.

Press the + or – buttons on the control panel to adjust the time.

When the time has been set, press the  button on the control panel to start the cooking process.


The maximum temperature which can be set is 200 Degrees Celsius.


The minimum temperature which can be set is 40 Degrees Celsius.

The maximum time which can be set is 1 hour.

The minimum time which can be set is 1 minute.

## PAUSE:

During the cooking process, press , the cooking will be paused. Press one more time, the cooking process will resume to work automatically.

If you want to stop the working process, hold pressing , it will stop working.

## Cooking Table:

The cooking times are a guide only.

They could vary depending on quantity, temperature and weight etc.

Food	Temperature	Time
Cashew Nuts	200°C	5~8 mins
Coffee Bean	200°C	20~25mins
Biscuits	180°C	10~15mins

Fish Sticks	180°C	6 ~ 10mins
Chicken nuggets	180°C	10 ~ 12mins
Chicken Breast	200°C	10 ~ 15mins
Drumsticks	200°C	15 ~ 20mins

**\*For cooking frozen food, please allow more time according to weight.**

### **Cleaning and Maintenance**

- Unplug the unit and let it cool completely before cleaning or maintenance.
  - Clean all parts thoroughly and dry after each use.
1. Once the unit has cooled, clean the glass container with warm soapy water and a damp cloth. Do not use abrasive materials, as this may scratch the surface. The glass container, mesh tray, and grill pan are dishwasher safe.
  2. For self-cleaning, add half an inch of water with mild liquid detergent.
  3. Set the temperature to 60°C, and the timer to 15 minutes, allowing residue to soften during heating. Unplug and let it cool completely before further cleaning.

### **Storing**

- Allow the unit to cool completely before storing. Store in a dry location and avoid placing heavy items on top to prevent damage.

---

#### **Distributed by:**

IDEAL WORLD

PO Box 443, Feltham TW13 9DU

Email: [customercare@idealworld.tv](mailto:customercare@idealworld.tv)

Tel: 0800 151 2345

Web: [www.idealworld.tv](http://www.idealworld.tv)