



homesmart®

Electric Juice Squeezer



INSTRUCTION MANUAL

Model: YC-302



Use your new Citrus Juicer to squeeze the juice from citrus fruit eg oranges, lemons, limes and grapefruits.

Before using your appliance

- Read these instructions carefully and retain them for future reference.
- Remove all packaging and any labels.

Safety

- Switch off and unplug:
 - before fitting or removing parts
 - after use
 - before cleaning.
- Never let the power unit, cord or plug get wet.
- Never use a damaged appliance.
- Don't let the cord touch hot surfaces or hang down where a child could grab it.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Only use the appliance for its intended domestic use. Seller will not accept any liability if the appliance is subject to improper use, or failure to comply with these instructions.

Important

. Don't press too hard on the cone or run for longer than 3 minutes - you may damage your juicer.

before plugging in

Make sure your electricity supply is the same as the one shown on the underside of the machine.

before using for the first time

1. Wash the parts: see 'cleaning'.
2. Wrap any excess cord around the bracket on the underside of the power unit **1**.

key

- 1 Dust Cover
- 2 Cone
- 3 Strainer
- 4 Juice Collector with Pouring Lip
- 5 Power Unit

To Use Your Citrus Juicer

1. Place the juice collector onto the power unit, hold the handle and turn until it matches well **2**.
2. Put the strainer inside the juice and collect until it matches well **3**, then add the cone **4**.
3. Cut the fruit in half. Then press each half down onto the cone and the juicer will operate automatically.
4. To help with juice extraction move the fruit from side to side.
5. To stop the juicer, lift the fruit from the cone.
6. To pour the juice, remove the cone and strainer from the juice collector and pour using the pouring lip.
7. When juicing large quantities, empty the strainer regularly to prevent the build-up of pulp and seeds. Empty the juice collector as required.

Cleaning

- . Always switch off, unplug and dismantle before cleaning.
- . Replace the dust cover after use.

power unit

- . Wipe with a damp cloth, then dry.

other parts

- . Wash in hot soapy water, then dry.
- . Alternatively, they can be washed on the top rack of your dishwasher.

Environment Protection

At the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection centre

Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin.

Distributed by:

Ideal World

PO Box 443, Feltham TW13 9DU

Email: customercare@idealworld.tv

Tel: 0800 151 2345